

Quick Tradeshow Pallet Repacking Instructions

1. Elevate runner chassis onto cross board on saw horses. Make sure saw horse legs far enough apart to clear pallet width.
2. Rotate wheels into upright position.
3. Slide pallet underneath frame ensuring runner is centered.
4. Lower runner lower frame onto pallet. **Be careful not to pinch brake lines.**
5. Collapse saw horses and cross arms.
6. Securely lower frame to pallet with ratchet straps (3). Below pallet decking run straps through hole cutout in provided notch. Use foam to protect wear areas under the strapping.
7. Lower upper frame securely onto lower frame support posts. (3/4" socket and ratchet is handy here).
8. Secure handle with red lanyard.
9. Shrink wrap box with foam blocks weaved in to support lid, front, and back walls.
10. Slide Install cardboard shroud around runner.
11. Secure sawhorses and loading boards to outer top sections of the pallet with heavy duty cable ties.
12. Final shrink wrap from pallet around whole runner.
13. Secure no stack cones to the top of the box.
14. Place no-stack stickers on box.
15. Takes photos prior to shipment and send to Marteen@rescue42.com